

nielsen®

1. Legen Sie die 4 Leisten mit der Sichtkante nach unten vorsichtig auf eine feste, ebene und saubere Unterlage zu einem Rahmen zusammen.

2. Tragen Sie auf die sich berührenden Gehungsfächen Leim auf.

3. Drücken Sie den Eckverbinder leicht in die dafür vorgesehene Öffnung.



4. Den Eckverbinder vorsichtig mit einem Hammer bündig einschlagen.

5. Wiederholen Sie die Schritte 2 – 4 mit den 3 weiteren Ecken.

6. Bei der letzten Ecke bitte die Gehung zusammengedrückt halten bis der Eckverbinder bündig eingeschlagen ist.



7. Befestigen Sie Ihren Keilrahmen mit den beigelegten Schrauben.

English manual

1. Put the 4 mouldings carefully with front side down on a solid, plane and clean base. Put them together as a frame.
2. Apply glue to the contacting mitre areas.
3. Slightly press the corner connection in the opening.
4. Carefully batter the corner connection in flush with a hammer.
5. Repeat steps 2-4 with the 3 other corners.
6. Press the last corner together until the corner connection is battered in flush.
7. Fix your canvas frame into the rim with the added screws.